WBS 1.1.2 Neutrino Beam Devices Target Hall Instrumentation Review

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 1

Agenda:


- Overview J. Hylen (15+5) min
- Electronics channels (readout into ACNET and Beam Permit, comprehensive list of channels, details of motor controls, LVDT's, thermocouples) R. Talaga (30+15) min
- Cross Hair System D. Ayres (15+10) min
- Recirculating Air System Controls A. Stefanik (15+10) min

(Times: minutes of talk + minutes allowance for discussion)



What is WBS 1.1.2 Scope? Neutrino Beam Production Devices and Target Pile

Review of WBS 112
Target Hall Instrumentation
November 18, 2002
Jim Hylen
Page 2



Target Hall Radiation Shielding

Hot (Radioactive) Component Workcell and Hot Handling Procedures/Tooling

Shield Pile Recirculating Air Cooling System

Lifting fixtures, transportation carts, magnetic field probes, prototyping, test stand, install



NuMI Target Hall

beam's eye view

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 3

Concrete Shielding

Temporary Stackup of removed shielding Steel from module middle Concrete from over horn Horn+Module in transit Stripline Concrete Cover "Carriage" - Module Support Beams Horn Shielding Module Horn Beam passageway (chase) is 1.2 m wide x 1.3 high, Steel Shielding forced-air-cooled Air Cooling Passage




Target Pile Shielding and Carriages

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 4

Carriages:

Cross-beams that modules hang from





Target Hall Instrumentation Scope of This Review

Review of WBS 112
Target Hall Instrumentation
November 18, 2002
Jim Hylen
Page 5

This review:

- Connection to ACNET (MADC, PLC) (Rich Talaga)
- Connection to beam permit system (Rich Talaga)
- Alarms and limits (Rich Talaga)
- Module motion control (Rich Talaga)
- Cross hairs alignment system (Dave Ayres)
- Recirculating-forced-air cooling system instrumentation (Andy Stefanik)

Devices not in review, but channel count / readout path is:

- Field monitor Bdot (have tested prototype)
- Target Budal (tested in target test), vacuum/pressure, horn-collision sensor
- Baffle Thermocouples (reviewed last August)
- Copy of horn currents
- Check of beam-to-horn-pulse timing (device not designed yet)

Not in this review:

- RAW (target & horn cooling water) is WBS 117
- Horn Power Supply is WBS 113
- Hot Handling camera system, hot cell controls (WBS 112 but no connection to outside systems)
- Transfer from ACNET to MINOS data stream Brett Viren (MINOS DCS, WBS 2.3)



General Level of Design

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 6

Channel count and requirements on channels (mostly) set (number, dynamic range, accuracy, alarm limits, beam permit usage)

Readout path (MADC, IRM, PLC) identified

Sensors identified (thermocouples, beam loss monitor chamber, pressure sensors, ...)

Some signal conditioning hardware is not yet designed:

- Integration, sample and hold on the beam pulse device signals which go to MADC
- Relative timing signal between beam (Budal and BLM) and horn (current and field)
- Signal conditioning for target/horn collision (short) sensor



Types of issues we would like reviewers to address

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 7

Are we integrating into ACNET in a reasonably optimized manner?

All signals (except internal PLC control of air system) will show up in ACNET as simple parameter pages. Is this sufficient for operations?

Does the set of instrumentation for the air system look reasonable? (e.g. we check that air is flowing by differential pressure rather than a flow sensor)

Other parameters that need specification before designing remaining hardware?

Review also brings management up to speed on current status.


Now on to a picture show to give more of a feeling what we are working with...

and some status of systems not covered by other speakers.

Radiation Levels

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 8


Power Supply Room: $\sim 1 - 10 \text{ Rad/yr}$ (MADC, differential pressure sensor, ...)



Chase, around horns: $\sim 10^{10}$ - 10^{11} Rad/yr (thermocouples, bdot coils, BLM ionization chamber)

NuMI MINOS

Target




Casing of target fin electrically insulated from base. Wire strung from case to top of module. When moving, can sense if case touches horn by short to "ground".

Narrow – location checked by scanning beam across edge.


Sense by:

- (i) charge (delta-rays) knocked out (wire connected to target) (called Budal)
- (ii) scattered beam into cross hairs ionization chamber (BLM)



Target and Horn Module Instrumentation: motor drives and thermocouples

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 10






Target/Baffle Carrier: motor drive and thermocouple

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 11

Moves Target by 2.5 m on beam axis along with water, vac., elec. lines. (extended travel aids in commissioning and monitoring)

Drive and position sensing is done behind shielding at top of module, only thermocouples are in high radiation environment





Horn (pion focusing device)

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 12

I=200 kA, 2 ms pulse Max. field 3 Tesla

Instrumentation:

Six thermocouples on outer conductor – difference in temperature top and bottom could cause warp of horn shape

Three bdot coils to monitor magnetic field (described later)

Cross hair system (described later)



Prototype horn 1 in test stand

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 13



beam

12 mm x 1 mm Aluminum

cross hairs mounted on horn

Function: Check position of horn w.r.t. beam by beam scan (target-out)

Scan: (1) horn 1 neck

(2) horn 1 downstream

(3) horn 2 upstream

(4) horn 2 downstream

Beam loss monitor ion chamber




Figure 9. Schematic of Tevatron loss monitor. The monitor is filled with argon gas at 725 mm of Hg. The guard electrode reduces the leakage current

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 14

3 bdot units per horn to monitor magnetic field each pulse

Tested prototype: 8 turns of 0.01 inch diameter 304 stainless steel wire

wrapped on MACOR form, 1.010 x 0.363 sq inch per turn

mounted to Aluminum Oxide ceramic feedthrough

In process of replacing MACOR with zirconia which is more radiation-hard (involves redesign of form for manufacturability, can't drill small holes) Bob Wagner has demonstrated significant thermo-electric effects at solder joints








Test at MI-8 of Bdot coil magnetic field monitoring pickup

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 15

Frank Nezrick demonstrated that sampling the off-pulse baseline and subtracting it from the signal gets rid of the thermally induced bdot instability

Goal of 0.4% stability has been achieved this way *Integrator built, but module to do subtraction in production DAQ has not been designed*






Baffle to protect target support and horn


Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 16

beam rms 1 x 1 mm Protects horn neck, target cooling tubes beryllium window support Target Casing 0.4 mm wall from beam accidents Target Horn inner Cooling conductor Instrumentation: Baffle 3 thermocouples banded //water/ water line to outer casing loop supporti near downstream end ring Bearn 1,2,3 sigma Target 150 cm **BAFFLE** Aluminum tube shrink wrapped 11.0 around graphite core with 18.0 11 mm diameter beam hole 19.0 30.0 60 mm

Baffle – cool! but not too cool!

Review of WBS 112
Target Hall Instrumentation
November 18, 2002
Jim Hylen
Page 17





Beam scraping on baffle affects spectrum

Tune cooling so 1% scraping \sim 20 C Δ T easy to thermocouple monitor scraping!

Done by covering 1/3 of baffle with

pin radiators: (air cool)



Baffle limit 100 deg C or 5% at 4e13ppp




Air Cooling System

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 18

Air system for target pile:

- (i) Recirculating to lower emission of radioactivated air
- (ii) 28,000 cfm to keep components cool and limit thermally induced misalignment
- (iii) Designed to remove 158 kw of the 400 kw total beam power
- (iv) Trying to keep relative humidity no more than 50%
- (v) High efficiency filter to capture radioactive contamination

Thermal model of module end-plate in target pile





Target pile cooling

Interlock to beam permit:


Air flow: differential pressure

Temperature: thermocouple at air entrance to target pile

Temperature monitoring:

Pile as shown (not reachable to replace)

plus thermocouples on modules






Hot Handling Equipment: cameras, lift table controls

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 20

Some items (camera systems, lead blanket on dolly as shielding for crane operator) we will develop during tests of handling at MI-8 after components are together.

A quick test with borrowed cameras of remote handling of T-block



T-block landing guide'



Hot handling camera system


Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 21

Cheap wireless TV transmission system is being tested.

Take signal from crane to upstream end of target hall

2.4 GHz transmitter


Antenna





Hot Work Cell To for change-out of activated components


Review of WBS 112
Target Hall Instrumentation
November 18, 2002
Jim Hylen
Page 22





Lifting Table in Hot Cell

Push horn or target up into module remotely – 5 degrees of motion



Hot cell lift table controls

Review of WBS 112 Target Hall Instrumentation November 18, 2002 Jim Hylen Page 24

Testing control system that came with lift tables.

May need modification. (e.g. table slowly sinks under load with controls off)





